



# WOOD FINISHES DIRECT

The following Product Datasheet is provided by **Liberon**

Wood Finishes Direct cannot be held liable for the information contained within this document.

For purchasing information visit:  
[Liberon Natural Finish Interior Varnish](#)



## Natural Finish Interior Varnish

- Maintains the natural look and feel of the wood
- Highly resistant to scratches and stains
- Water based, low VOC
- Quick drying



### USAGE

Interior

### COVERAGE

1 Litre

10-12 m<sup>2</sup>

### APPLICATION

Brush or roller

### DRYING TIME

minimum 2 hours

### TOOL CLEANING

Water

### Product use

Liberon Natural Finish Interior Varnish is a hardwearing and long-lasting varnish which is ideal for use on soft or hardwood furniture and most interior woodwork; such as skirting boards, doors, work surfaces and panelling. Keeping the natural feel and look of the timber Natural Finish Interior Varnish uses a non-yellowing and quick drying formula.

### Preparation

Sand the wood if required and remove all previous finishes. Ensure the surface is clean, dry and free from dust. If you want to colour the wood, you can apply Liberon Palette Wood Dye to the timber before varnishing. Alternatively Liberon Palette Wood Dye may be added to the varnish to create unique colour tones. Liberon Palette Wood Dye is available in a range of wood shades.

### Application

Shake/stir well before use. Apply a reasonable coat of varnish evenly using a paint brush or short hair roller and allow to dry for a minimum of 2 hours before applying further coats. We recommend a minimum of 3 coats are applied, sanding lightly between coats if required. More coats may be required for items which are in heavy use. Allow the final coat of varnish a minimum of 24 hours drying time before use.

**Important:** Always test product on a spare surface or inconspicuous area for colour compatibility and end result.

### Cleaning and maintenance

Wipe any spills immediately. For general maintenance wipe over with a damp cloth using a mild detergent if required. If the surface shows signs of wear re-apply a coat of varnish.

### Precautions

Allow all wood dyes to dry for a minimum of 8 hours before applying Natural Finish Interior Varnish. Care must be taken on the application of the first coat of Natural Finish Interior Varnish when being used over Liberon Palette Wood Dye. Keep brush strokes to a minimum as over brushing may lift out the colour. The varnish may raise the grain on some hard woods. Do not exceed a 10% dilution of Natural Finish Interior Varnish with Liberon Palette Wood Dye. Natural Finish Interior Varnish is not suitable for applying over an oil-based finish.

### Liberon Advice

In order to avoid bubbles forming on the surface of the varnish when using a roller, we recommend the use of a short hair roller and that work is not carried out at temperatures above 25°C. Apply successive coats in a criss-cross format (right to left then left to right) applying the final coat in the direction of the grain.

### Packaging

Natural Finish Interior Varnish is available in 1 L containers.

**Health and Safety**

Keep out of the reach of children. Do not empty into drains. Use only in well-ventilated areas. Do not allow to freeze.

**VOC information**

EU limit value for Natural Finish Interior Varnish (CatA/I): 140 g/L (2007) / 140 g/L (2010). Natural Finish Interior Varnish contains Max 0.5 g/L VOC.