



WOOD FINISHES DIRECT

The following Technical Datasheet is provided by **Protek**

Wood Finishes Direct cannot be held liable for the information contained within this document.

For purchasing information visit:
[Protek Stain Block Primer](#)

Product Description

Protek Stain Blocking Primer is effective at blocking tannins, pressure treated chemicals and rust (from nail heads) bleeding through to the topcoat. We would recommend using this Primer when white or light colours are used as a top coat to stop unsightly yellow staining coming through.

Protek have developed an excellent water based stain blocking primer that offers better performance than both current water based and solvent borne products.

- Excellent tannin blocking performance
- Fast drying, can be top coated in an hour.
- Can be used in low temperatures.
- Cationic primer with flash rust resistance for nail heads.
- Low VOC



Recommended Use

Protek Stain Blocking Primer puts down a clear layer than gives an even base for top coats to be applied over. It is especially recommended for use on new timber when unsightly tannins or pressure treatment might leach through the coating. This is not usually an issue with natural wood colours but if a white or off-white colour is used we would recommend applying this first.

Number of coats required

For best results it is recommended 2 coats are applied before the topcoat.

Coverage

1 litre will cover approximately 8m² per coat depending on the moisture content and porosity of the surface.

Surface Preparation

Surfaces should be clean and dry before application. If surfaces need to be cleaned we recommend warm water with detergent and a stiff brush.

Application

Mix well before use.

Protek Stain Blocking Primer can be applied by spray, brush or roller. Allow each coat to dry before applying the next; this should take up to 1 hour. We recommend 2 coats especially if a white or off-white topcoat is being applied.

If applying to bare untreated timber we recommend first applying a Wood Preserver before the primer. This primer will stop the tannin bleed from knots in the wood but it will not stop the resin coming through. If the timber is resinous a knotting agent should still be applied to the knots.

Use with care

Protek Stain Blocking Primer MUST be fully dry before applying the top coat.

Brushes must be fully washed out before using with the top coat.

In their wet forms Stain Blocking Primer and other top coats are not compatible and should never be mixed.