

The following Product Datasheet is provided by **V33**

Wood Finishes Direct cannot be held liable for the information contained within this document.

For purchasing information visit: V33 Renovation Cupboard and Cabinet



HIGH PERFORMANCE FOR YOUR RENOVATION

Renovation CUPBOARD & CABINET paint has been specially developed to renovate high traffic surfaces. Thanks to a complex combination of exclusive polymers, the paint is extremely durable and resistant to culinary and domestic stains. It allows regular and easy cleaning without altering the colour and finish of the paint.













- 2 in 1: no undercoat.
- Impact and scratch resistant.
- Resistant to culinary stains: hot and cold fats, vinegar, wine, ketchup, coffee and tea....
- Resistant to care and maintenance products: water, washing up liquid, multi purpose cleaner, household products, diluted bleach...
- Easy application: perfect finish.
- Ultra washable: easy maintenance.

COLOURCHART – Satin aspect





NO UNDERCOAT - NO STRIPPING

Drying time

Recoat: **6h** – Fully dry: **24h** Tools cleaning: **water**

COVERAGE:

 $750ml = +/- 10m^2 - 2L = +/- 24m^2$

Paint developed for new or old kitchen furniture, suitable for use on:

- Raw, varnished or painted woods
- Melamine, laminate
- Tiles, plaster, glass

Not suitable for bathroom tiles.

TOOLS:

- Paint stirrer or wide stick
- 4-5mm short pile roller
- Round edeged paint brush (for angles, corners & finishes)

PREPARATION:

PREPARATION of the surface is ESSENTIAL.

WASH the surface with a soda-based or sugar soap (alkaline) cleaner.

- VARNISHED WOOD, PAINTED WOOD and MELAMINE: wash, rinse thoroughly with water, leave to dry, then lightly sand with 240 grit sandpaper and remove dust.
- LAMINATE, WALL TILES and GLASS: wash and rinse thoroughly with water, leave to dry...
- RAW/POROUS SURFACES (wood, mdf): lightly sand and remove dust.

On raw oak and chestnut, first apply an appropriate undercoat to block the tannins.

APPLICATION:

Apply the paint at room temperature between 12 and 25°C and avoid draughts.

- 1. Stir the paint with a stirrer or wide stick, working around the bottom of the tin to mix it well.
- 2. Start by painting the angles, moldings and joints of the surface. Work on small surfaces. Apply from one end to the other. Follow with successive cross strokes. Do not start 2nd coat while it's still drying. Leave to dry for 6h (do not exceed 12h) and apply a 2nd coat in the same way. A 3rd coat may be required depending on the surface and colour.

V33 TIPS:

To clean your painted surfaces, use a gentle detergent and a non-abrasive sponge.

Optimum product performance and adhesion is achieved after 20 days from application. Treat the surface gently, avoiding direct impact, abrasion, staining or cleaning, for the first 20 days after application.







