



WOOD FINISHES DIRECT

The following Product Datasheet is provided by **Liberon**

Wood Finishes Direct cannot be held liable for the information contained within this document.

For purchasing information visit:
[Liberon Retouch Cream](#)



Retouch Cream

- A soft wax for rubbing into damaged areas
- Restores colour and disguises dents and chips
- Ideal for filling mitre joints and pin holes on frames or furniture
- Dries hard
- All colours are intermixable



Product use

Liberon Retouch Cream is a soft creamy wax for filling mitre joints and pin holes on frames or furniture for restoration. It is also used to colour scratches and small defects.

Preparation

Ensure surface is clean, dry and free from dust.

Application

Apply to the damaged surface with a cloth. Gently remove any excess with a cloth. Allow to dry for a minimum of 20 minutes, longer if possible, then buff lightly with a lint-free cotton cloth.

Tools can be cleaned with white spirit. If the product dries out it can be re-activated by gently warming and adding white spirit.

Colours: White, Black, Mahogany and Light Oak.

Packaging

Liberon Retouch Cream is available in 30 ml containers.

Health and Safety

Irritant. Flammable. May cause sensitisation by skin contact. Harmful to aquatic organisms, may cause long-term adverse effects in the aquatic environment. Repeated exposure may cause skin dryness or cracking. Keep out of the reach of children. Avoid contact with skin. Do not empty into drains. Wear suitable gloves. Use only in well-ventilated areas. If swallowed, do not induce vomiting: seek medical advice and show this container or label.