

A decorative graphic in the top left corner consisting of concentric, wavy orange lines that resemble the grain of wood, curving downwards and to the right.

WOOD FINISHES DIRECT



Finish. Finished.

The following Product Datasheet is provided by **Ronseal**

Wood Finishes Direct cannot be held liable for the information contained within this document.

For purchasing information visit:
[Ronseal Decking Cleaner and Reviver](#)

Fast acting formula cleans and revives all types of decking

Ronseal Decking Cleaner & Reviver is specially formulated to clean and revive weathered or tired timber decking.

Our fast acting formula removes moss, mould and algae whilst also brightening the wood and restoring it back to its natural appearance.

It is ideal for use prior to treatment, opening the pores of the wood, allowing maximum adhesion of the coating and a longer lasting finish. Not only that, it can also be used as a general cleaner, brightening and enhancing your deck throughout the season.

Usage Areas	Ridged or smooth hardwood and softwood decking.
Compatibility	Weathered and treated decking.
Coverage	This 5L pack is sufficient to cover approx 20-24m ² .
Clean Up	Clean equipment in warm water and detergent.

Preparation

Always test on an inconspicuous area before use to ensure you achieve the desired result. Remove debris and accumulations of moss, mould and algae using a stiff brush.

Application

1. Pour Decking Cleaner & Reviver directly onto your deck.
2. Scrub the surface immediately using a stiff brush then leave for 15-20 minutes.
3. For best results wash thoroughly with a pressure washer. Work from one end of a decking board to the other in a continuous motion. Alternatively scrub the surface using a stiff brush then hose down.
All cleaning residues must be completely washed away to maximise the performance of subsequent coatings.

Clean up

The surface may become slippery during cleaning. If Decking Cleaner & Reviver comes into contact with surrounding grass or plants rinse thoroughly with water. Please note that Decking Cleaner & Reviver may remove partially deteriorated coatings. Do not allow undiluted product to enter drains or watercourses.

Maintenance

Use Decking Cleaner & Reviver regularly to enhance the look of your deck. Decking should be inspected on an annual basis and re-coated as appropriate with a Ronseal finish: Decking Stain for durable colour and protection or Decking Oil for natural colour and nourishment.

5 litres e

Ronseal Ltd., Chapeltown, Sheffield S35 2YP
Tel: 0114 246 7171 Email: enquiry@ronseal.co.uk

Ronseal and Ronseal Does Exactly What it Says on the Tin are registered trademarks of The Sherwin-Williams Company. © 2012

Wise Precautions



Avoid contact with skin and eyes. In case of contact with eyes rinse immediately with plenty of water and seek medical advice. Do not breathe spray. In case of insufficient ventilation wear suitable respiratory equipment. Keep out of the reach of children. Protect from frost.

Contains

Less than 5% Non-Ionic surfactants

Less than 5% Phosphate

Preservatives



For more help & advice, visit us at

www.ronseal.com

or ring us on
0114 240 9469

Does exactly what it says on the tin®