



**WOOD
FINISHES
DIRECT**



Finish. Finished.

The following Product Datasheet is provided by **Ronseal**

Wood Finishes Direct cannot be held liable for the information contained within this document.

For purchasing information visit:

[Ronseal Hardwood Garden Furniture Restorer](#)

Ronseal Hardwood Garden Furniture Restorer Information Sheet

Non- acid based gel formula that will restore and revive grey hardwood back to its natural colour without the need for heavy sanding.

Where	Any bare hardwood garden furniture
Coverage	6-8m ² /L
No. Coats	1 – retreatment may be needed for very grey wood.
Working Time	15 minutes, once applied and scrubbed in.
Application method	Brush apply.
Clean Up	Wash all tools out in warm soapy water.

Clean off any dirt with a stiff brush.

Make sure it doesn't dry out. More product will need to be applied and scrubbed in if it does.

To check if it has fully worked scrub an unobtrusive area and wash clean to check colour.

Make sure all of the restorer is fully rinsed off before allowing to dry.

While the furniture is still wet the colour change may not be so apparent. Leave it to dry slightly before checking to see if it has been sufficiently restored. If not then another coat of restorer will be needed.

Allow to fully dry before applying any stain or oil to your furniture.