

A decorative graphic in the top left corner consisting of concentric, wavy orange lines that resemble the grain of wood, curving downwards and to the right.

# WOOD FINISHES DIRECT



Finish. Finished.

The following Product Datasheet is provided by **Osmo**

Wood Finishes Direct cannot be held liable for the information contained within this document.

For purchasing information visit:

[Osmo Garden Furniture Maintenance Kit](#)



## TEAK-OIL SPRAY

Easy to use and high coverage - penetrates deeply into wood!



008 Clear



### PRODUCT DESCRIPTION

Clear, water and dirt-repelling oil to protect and maintain garden furniture and decking. Osmo Teak-Oil Spray penetrates deeply into the wood surfaces, regulates thereby moisture and prevents swelling and shrinkage. The microporous oil coating does not crack, peel or flake. To refresh, simply reapply (No sanding – no sanding dust!).

### RECOMMENDED USE

Osmo Teak-Oil Spray protects, maintains and improves the appearance of garden furniture made of Teak and other hardwoods – in covered exterior areas. It is also well suited to the clear finishing of garden furniture and similarly used surfaces.

### INGREDIENTS

Based on natural plant oils (sunflower oil, soya oil, thistle oil and linseed oil), siccatives (drying agents) and water-repelling additives. Dearomatized white spirit (benzene-free).

Detailed declaration of ingredients available upon request.

### TECHNICAL DATA

Specific gravity: 0.85-0.9 g/cm<sup>3</sup>

Viscosity: not applicable

Odour: characteristic

Flash point: not applicable, aerosol

### STORAGE

Up to 2 years and longer if can is kept dry and closed tightly.

### SURFACE PREPARATION

Wood surface must be clean, dry and frost-free (moisture content max. 20%). Osmo Teak-Oil Spray is ready to use. Shake spray can well and carry out trial spray. Clean old microporous stains thoroughly. Old paints and lacquers must be completely removed. As a general rule, wear a dust mask during sanding works.

Hard wood containing natural wood ingredients needs to weather off (for approximately 4 weeks) or be cleaned with Osmo Brush Cleaner and Thinner (degreaser). The finished surface is, among other things, influenced by the wood's natural characteristics. Therefore, a trial application is always required, especially for unfamiliar surfaces.

### METHODS OF APPLICATION

Spraying distance approx. 25 cm. Afterwards massage into wood with a brush.

While applying, cover and protect surrounding areas and parts which should not be treated against the spray mist.

Wipe away any excess product with a cloth.

Allow to dry for approx. 12 hours with good ventilation and apply 2nd coat.

When renovating, one coat applied is usually sufficient.

Clean spray nozzle after use.

### CLEANING OF TOOLS

With Osmo Brush Cleaner (free of aromatic compounds).

### DRYING TIME

Approx. 12 hours (normal climatic conditions, 23 °C/ 50 % rel. humidity). Lower temperatures and/or higher air humidity can increase the drying time. Allow for good ventilation while drying.



## COVERAGE

1 litre covers approx. 5-10 m<sup>2</sup> with one coat.  
Product coverage depends significantly on the character of the wood. All information refers to smooth and planed/cut surfaces. Other surfaces may lead to reduced coverage.

## NOTE

Osmo Teak-Oil Spray is clear and therefore it does not protect against UV rays from the sun (greying). If the original colour tone of freshly sawn wood should be kept (e.g. Bangkirai), we recommend a coat with Osmo Decking-Oils in a natural shade or Natural Oil Woodstain in the appropriate colour tone.

## CAUTION

Extremely flammable aerosol. Pressurised container: May burst if heated. Do not spray on a naked flame or any incandescent material. Keep away from sources of ignition - No smoking. Pressurised container: Do not pierce or burn, even after use. Protect from sunlight. Do not expose to temperatures exceeding 50 °C. Keep out of the reach of children. Do not get in eyes, on skin, or on clothing. Do not breathe spray. Use only outdoors or in a well-ventilated area. If medical advice is needed, have product container or label at hand. Warning: Wash out any used cloth impregnated with this product immediately after use or store in an airtight container (danger of self-ignition). Must not be applied on the same spraying stand as lacquers or lacquer corrosives that contain NC (nitrocellulose). Risk of self-ignition. Please stick to the regulations of the BG Holz (BGI 740 for coating units) and the BGV D 25 of the insurance association and the technical leaflet. Safety data sheet available on request.  
Propellant: propane/butane.

Danger



## DISPOSAL

Dispose of leftover product and completely emptied packaging according to local official guidelines (waste code number 08 01 11). Only completely emptied cans can be recycled.

## COLOUR TONE

008 Clear

## CAN SIZES

0.4 L

The above mentioned information is provided to the best of our knowledge however without any liability.

Version 10/15